Размеры женской о	дежді	ы										
Английский размер	6	8	10	12	14	16	18	20	22	24	26	28
Европейский размер	34	36	38	40	42	44	46	48	50	52	54	56
Бюст (дюймы)	311/2	33	34	35½	37	39	41	43	45	48½	50½	521/
Бюст (см)	80	84	86,5	90	94	99	104	109	114	123	128	133
Талия (дюймы)	241/2	25½	27	28	30	32	34½	37	38½	43	453/4	48%
Талия (см)	62,5	65,5	68,5	71	76	81	87,5	94	98	109	116	123
Бедра (дюймы)	33	34½	36	37½	39½	41½	43½	46	48½	51½	54	563/
Бедра (см)	84	87,5	91,5	95,5	100,5	105,5	110,5	117	123	131	137	144
	Petit	e		Stand	dard	Je.	Long		200	Tall		
Рост	4'11"-5'3"		5'3"-5'6"			5'6"-5'10"			5'10"+			
	150-160cm			160-167.5cm			167.5-177.5cm			177.5cm+		

ADVA	
BEGI	NNER

SKILL LEVEL

multisized pattern...sizes 6/8/10/12/14/16 /18/20/22/24/26 all together!



more than a spritz of your favorite scent!


Размеры женской о	дежді	əl										
Английский размер	6	8	10	12	14	16	18	20	22	24	26	28
Европейский размер	34	36	38	40	42	44	46	48	50	52	54	56
Бюст (дюймы)	31½	33	34	35½	37	39	41	43	45	48½	50½	521/2
Бюст (см)	80	84	86,5	90	94	99	104	109	114	123	128	133
Талия (дюймы)	24½	25½	27	28	30	32	34½	37	38½	43	45¾	481/4
Талия (см)	62,5	65,5	68,5	71	76	81	87,5	94	98	109	116	123
Бедра (дюймы)	33	34½	36	37½	39½	41½	43½	46	48½	51½	54	56¾
Бедра (см)	84	87,5	91,5	95,5	100,5	105,5	110,5	117	123	131	137	144
	Petite			Standard			Long			Tall		
Рост	4'11"-5'3"			5'3"-5'6"			5'6"-5'10"			5'10"+		
	150-160cm			160-	167.5cm	n	167.5-177.5cm			177.5	5cm+	


PrintTemp -- Col: 5 Row: 3 -- 1 of 23


Hoth

											C
SIZE 26	SIZE 24	SIZE 22	SIZE 20	SIZE 18	SIZE 16	SIZE 14	SIZE 12	SIZE 10	SIZE 8	SIZE 6	

PrintTemp -- Col: 5 Row: 4 + 2 of 23







Hot Patterns & fabric.com

exclusive free download cupid cami & tap pants instructions page 1 of 2

SEAM ALLOWANCES & OTHER INFO

Seam allowances are 5/8" or 1.5 cm wide; all seams are sewn right sides together unless otherwise stated.

The neckline and armholes on the Cami are finished with self fabric bias binding; the bottom edges of the Cami &Tap Pants are finished with narrrow hems.

Skills needed include: making & applying bias binding; making & applying an elastic waist casing; working a narrow hem..

ABOUT THIS STYLE


The Cami & Tap Pants have an semi-fitted, slightly relaxed silhouette.

We haven't included a pattern for the bias binding... you just need to cut enough strips of 1 1/2" or 3.75 cm wide fabric to go around each armhole, plus enough to go twice around the neckline.


Oh yes, as always, make & fit a muslin before you cut into your fabric...in this case, use a cheap fabric with a similar drape to your chosen fabric.

SUGGESTED CUTTING LAYOUT FOR THE CAMI fold fabric in half, with selvedges

told fabric in half, with selvedges to the middle for this layout



SUGGESTED CUTTING LAYOUT FOR THE TAP PANTS fold ribbing in half, with selvedge to selvedge for this layout




FABRIC & NOTIONS REQUIRED

You'll need around 1 1/4 yards/ 112 cm of 60"/150cm wide fabric for the cami. You'll need around 1 yard/ 90 cm of 60" / 150 cm wide fabric for the tap pants, plus enough 1/2" or 1.25 cm wide elastic to circle your waist.

1a Start by preparing the bias binding.


Join the short ends of each piece to make a long strip.




1 Press the seams open, then feed your bais strips hrough a bias binding folder, pressing as you go.

Set aside until step X.


2 Join the front to the back along the side seams; and press the seams open.





FOLD


exclusive free download cupid cami & tap pants cami front cut 1 on fold in fabric





Hotel atterns & fabric.com


exclusive free download cupid cami & tap pants front cut 1 pair in fabric



instructions page 2 of 2

Apply the bias binding to the front neckline:working on the wrong side, sew the binding to the neckline curve along the crease line on the binding.

3a



Following the markings on the pattern, baste these ribbons to the wrong side of the back neckline of the cami.

5




Repeat steps 3a and 3b, this time on one of the cami front armholes, and working around to the back, then up to the 6 end of the remaining armhole.

> You'll catch the ends of the back ties in as you sew the bias binding on.


IMPORTANT: leave about 12' or 30 cm of bias binding 'free' at each end of the armholes....these will become your ties.

3b



Fold the binding onto the right side of the fabric,

and sew down the remaining edge. Press flat.




Cut two sections from your bias binding, each measuring about 18" or 45 cm long...these will be your back ties.

7


Work a narrow hem along the bottom edge of the cami, and press flat.


Repeat step 4b to complete the ties.



4b

Fold these strips in half lengthways and sew along the outer edges to give you a pair of 'ribbons'.





Hot Patterns & fabric.co


exclusive free download cupid cami & tap pants cami back


MITHE - dir manistald in fahric


cut i un iulu in iabiic

FOLD

PrintTemp -- Col: 7 Row: 4 14 of 23








Instructions for making the Tap Pants

Join the elastic waist casing pieces to create a loop.


Press the seams open, then fold in half lengthways.

Press flat, then set aside until step X.




2 Matching all notches and easing where necessary, join the backs along the center back seam.

Press the seam open.




Repeat step 2, this time using the fronts.



4 Matching all notches and easing where necessary, join the front to the back along the side seams.

Press the seams open.




Starting at the crotch point, join the front to the back along the inner leg seam. Press all seams open.

Apply the elastic waist casing: match the seams on the elastic waist casing to the center front and center back seams on the panties.

Starting about 1" or 2.5cm away from the center back, join the elastic waist casing to the top edge of the panties, making sure you sew through all 3 layers.

Stop sewing about 1" or 2.5cm away from the center back seam, leaving you with about 2" or 5cm where the elastic waist casing isn't attached to the panties.



Measure your elastic by pulling it gently around your natural waist...don't pull it too tight, it needs to be comfortable!. When you are satisfied that you have the correct amount of elastic, cut to size...


DO NOT add seam allowances to the elastic, as it will stretch out with wear & laundring.

Thread the elastic through the waist elastic casing.


Pull both ends out and join them, overlapping them by 5/8" or 1.5cm.

Stretch the waistband until the joioned ends of the elastic go back into the waistband, then sew the final 2" or 5cm of the waistband to the panties.


9 Hem the panties by 5/8" or 1.5cm.
D-O-N-E!





m											
1111			0	2	14	16	18	20	22	24	= 26
	9 山	8 四	至1	ZE 1	. 3 Z	ZE	JZE	3ZI	SIZE	SIZE	SIZE
	SIZ	SIZ	<u>S</u> Z	.1S	S			Row: 3			




97 37S 37S 37S PrintTemp -- Cet: 8 Box: 4-2012s









free download ami & tap pants istband air in fabric

